

Favor Boxes are easy to assemble! Use these instructions to help guide you through your first few boxes. (We've even included a few extra boxes for you to practice on, but you'll be a pro in no time.)

## INSTRUCTIONS


### Getting Started



1. Pre-fold your tabs by lightly bending at each fold line. Pre-folding will make it easier to form each part of your box later on.

2. Hold the piece so that the left outer tab (A) is faced up and the right outer tab (B) is faced down.


### Forming the Sides



1. Fold the two outer tabs (A and B) toward the inside of the box.



2. Bring the two outer tabs (A and B) toward each other to form the four sides of your box.



3. Slide tab B down and into tab A to secure the four sides. (Make sure the tabs are inside the box—see photo).

# Assembly Instructions for Wedding Favor Boxes

Rectangle, Square, and White Boxes with Labels


We're Here for You 800.788.0611



1. Fold in the U-shaped tab (C) first.



2. Fold the two side tabs (D and E) over the U-shaped tab (C).



3. Fold the final tab (F) over the first three tabs, then secure in place by gently tucking it into the slit formed by the first three tabs.



1. To line the side and bottom of your box, gently push the tall flap (G) down, bending at the fold line to help form into place.



2. Fold the two side tabs (H and I) in toward each other, then fold the tabbed part (J) of the final flap in.



3. Fold the final flap down, tucking the tabbed part in to secure the top of your box.

Congratulations! You've assembled your first Favor Box. To finish the rest, pump up the folding fun by enlisting the help of a few friends and adding some background music. Enjoy your beautiful display of personalized Favor Boxes!